




*M222 straw 167 (B) dead straw*



*dG = 2.7 rms = 1.25 dead section*




**g222 Gain Correction**




**g222 Sigma (along straw length)**

**g222 Number of Data**


***M222 straw 520 (B) Low gain straw***



***dG = 4.2 rms = 2.16 Low gain points***




**g222 Gain Correction**




**g222 Sigma (along straw length)**

**g222 Number of Data**


***M222 straw 474 (F)  $\Delta G > 8\%$***



***$dG = 8.6 \text{ rms} = 3.06 \text{ Hung Wire}$***




***g222 Gain Correction***




***g222 Sigma (along straw length)***

***g222 Number of Data***

***M222 straw 015 (B)  $\Delta G > 8\%$***




***$dG = 8.4 \text{ rms} = 2.93 \text{ Bent Straw}$***



**g222 Gain Correction**

**g222 Sigma (along straw length)**



**g222 Number of Data**