



***M235 straw 263 (F)  $\Delta G > 8\%$***




**g235 Gain Correction**

***$dG = 10.4 \text{ rms} = 2.12$  Low gain region***




**g235 Sigma (along straw length)**




**g235 Number of Data**

***M235 straw 092 (B) Low gain straw***




**g235 Gain Correction**

***dG = 2.2 rms = 1.16 Displaced WJ***




**g235 Sigma (along straw length)**




**g235 Number of Data**

*M235 straw 370 (B) Low gain straw*




**g235 Gain Correction**

$dG = 1.9 \text{ rms} = 1.09 \text{ Displaced WJ}$




**g235 Sigma (along straw length)**




**g235 Number of Data**

***M235 straw 405 (B)  $\Delta G > 8\%$***




**g235 Gain Correction**

***$dG = 20.3 \text{ rms} = 8.05 \text{ Displaced WJ}$***




**g235 Sigma (along straw length)**




**g235 Number of Data**


***M235 straw 501 (B)  $\Delta G > 8\%$***



***dG = 9.4 rms = 5.97 Bent Straw***




**g235 Gain Correction**




**g235 Number of Data**

**g235 Sigma (along straw length)**

***M235 straw 447 (B)  $\Delta G > 8\%$***




***$dG = 8.6 \text{ rms} = 2.31 \text{ low gain pt}$***



**g235 Gain Correction**

**g235 Sigma (along straw length)**



**g235 Number of Data**